




Asennusohje Urimat Ecoplus, Ecovideo




1 x 21.001 ECO




1 x 44.100 / Display Cover
1 x 42.002 / Spacer



1 x 30.978 Netzteil 12V
1 x 30.981KU / Display USB
1 x 30.981K / Display HDMI
1 x 44.181 / Display Cover



1 x 58.405/ Mounting Bracket
2 x 57.350 / Nut




2 x 57.300 Counter Sunk Screw
2 x 58.701 Distance Washer / Bush



2 x Screw - Washer - Dowel



1 x 56.111 / Sheeve



1 x 52101 / MB Trap




1 x 66.010 / Seal

15.06.2022/mr/Rev.04





Asennusohje Urimat Ecoplus, Ecovideo

Seinäviemäröinti.
Myös lattiaviemäröinti mahdollinen.







novosan



Sähkökytkentä:
Videonäyttöliselle
Ecovideo-pisuaarille.

**Pisuaari lasten
korkeudelle :**
Asenna 200 mm alemmas.

* 110V - 230V only used for URIMAT ecovideo



Novosan Oy

asiakaspalvelu@novosan.fi p. 09-478 922 31 myynti@novosan.fi p. 09- 425 770 20

www.novosan.fi